


The QL Advanced User Guide

Adrian C. Dickens BA,
Churchill College,
Cambridge University



Published by Adder Publishing, Cambridge

Contents

1 Introduction	9
1.1 General introduction	9
2 The 68008 microprocessor	10
2.1 Introduction for those new to machine code	10
2.2 Programmer's model	13
2.2.1 Data registers	13
2.2.2 Address registers	14
2.2.3 Stack pointers	14
2.2.4 Program counter	15
2.2.5 The status register	15
2.2.6 Interrupts	15
2.3 Data organisation in memory	16
2.4 Traps and exception processing	17
2.5 Effective addresses	18
2.5.1 Register direct modes	18
2.5.2 Memory address modes	19
2.5.3 Special addressing modes	20
2.6 Instruction set summary	21
2.6.1 Data movement operations	22
2.6.2 Integer arithmetic operations	23
2.6.3 Logical operations	23
2.6.4 Shift and rotate operations	24
2.6.5 Bit manipulation operations	25
2.6.6 Binary coded decimal operations	26
2.6.7 Program control operations	26
2.6.8 System control operations	27
3 QDOS — an overview	28
3.1 Introduction	28
3.2 QDOS and system control	30
3.2.1 Memory management	33
3.2.2 Resource allocation	33
3.2.3 Task scheduling	33
3.3 Job input and output	35
3.4 Support for user programs	35

Published in the United Kingdom by:
Adder Publishing,
PO Box 148,
Cambridge CB1 2EQ

ISBN 0 947929 00 2

Copyright © 1984 Adder Publishing
First published August 1984

The Author would like to thank Nigel Dickens, Tim Gleeson, Mark Plumbley, Tony Tebby, Ken Vail, Albert Williams and everyone else who helped in the production of this book.

All rights reserved. This book is copyright. No part of this book may be copied or stored by any means whatsoever whether mechanical, photographic or electronic, except for private or study use as defined in the Copyright Act. All enquiries should be addressed to the publishers. While every precaution has been taken in the preparation of this book, the publisher assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of information contained herein.

The Author would like to thank Motorola Semiconductors for their permission to reproduce diagrams from their MC68008 data sheet. These diagrams remain copyright of Motorola.

Please note that within this text, QL and QDOS are trade marks of Sinclair Research Limited.
Quill, Abacus, Easel and Archive are trade marks of Psion Limited

This book was prepared using the Acornsoft VIEW wordprocessor on the BBC Microcomputer and then computer typeset by Parker Typesetting Service, Leicester. Book production by Adder Publishing.

Printed in Great Britain by The Burlington Press Ltd., Foxton, Cambridge.

4 Experimenting with QDOS	37
4.1 Introduction	37
4.2 From SuperBasic to machine code	38
4.3 The Experimentor program	41
4.3.1 Introduction to the Experimentor	41
4.3.2 Program listing	42
4.3.3 How the Experimentor works	45
4.3.4 Experiments	47
4.4 Programming in Assembler	53
4.4.1 Real time clock example	53
4.4.2 Self-cloning program example	55
5 Manager traps	60
5.1 Introduction to manager traps	60
5.2 Memory management on the QL	60
5.2.1 Resident procedures	61
5.2.2 Jobs as transient programs	63
5.2.3 Memory allocation for Basic programs	63
5.2.4 Common heap allocation	63
5.2.5 User heap allocation	66
5.3 Managing the hardware	68
5.3.1 Standard QL hardware	68
5.3.2 QDOS extensions	68
5.4 Manager traps – reference section	70
5.3.1 Creating and deleting Jobs	72
5.3.2 Job control	79
5.3.3 User heap management	85
5.3.4 Communicating with the IPC	91
5.3.5 Extending the operating system	103
6 Input/Output Allocation traps	111
6.1 Introduction to input and output	111
6.2 Specification of device names	112
6.3 Filing system names specification	113
6.3.1 Requirements of names	113
6.3.2 Approach to filing system names	114
6.3.3 Components of filenames	115
6.4 Opening files	115
6.4.1 General introduction	115
6.4.2 Order of search for files	116
6.5 I/O allocation traps	119
7 Input/Output Utilisation traps	124
7.1 Introduction	124
7.1.1 Serial I/O calls	124
7.1.2 Screen output control	127
7.1.3 File handling	127
7.2 Serial I/O calls	128
7.2.1 Serial I/O return options	130
7.2.2 Serial I/O traps	130
7.3 Screen output control traps	137
7.3.1 User screen drivers	138
7.3.2 Finding the window size	140
7.3.3 Window control	142
7.3.4 Cursor control	152
7.3.5 Scrolling windows	155
7.3.6 Panning windows	158
7.3.7 Clearing windows	163
7.3.8 Setting the character font	164
7.3.9 Setting the character attributes	174
7.3.10 Block filling	175
7.3.11 Graphics traps	182
7.4 Filing system traps	192
8 Vectored Utilities	192
8.1 Introduction	192
8.2 Supervisor mode routines	195
8.3 Simplified trap routines	202
8.4 General utility routines	209
8.4.1 Linked list management	209
8.4.2 User heap management	211
8.4.3 Queue handling routines	213
8.4.4 I/O device name utility	218
8.5 SuperBASIC utility routines	219
8.5.1 Comparison of strings	219
8.5.2 Conversion routines	222
8.5.3 Procedure support routines	240
8.5.4 Arithmetic routines	247
8.5.5 SINH as a resident function	252
8.6 Microdrive support routines	255

9 Device drivers	259	Appendices	
9.1 Introduction	259	A Memory map	296
9.2 Device driver definition blocks	260	B 68008 instruction set summary	297
9.3 Access layer	262	C Plug in ROM specification	298
9.3.1 Opening a channel	262	D Microdrive format	301
9.3.2 I/O to a channel	263	E Screen layout	311
9.3.3 Closing a channel	263	F Hardware expansion specification	313
9.4 Physical layer	264	G Error codes	318
9.5 Decoding device names	265	H Trap summary	319
9.5.1 Device name description	266	I Vectored Utilities summary	323
9.6 Memory allocation	267	J SuperBasic variables summary	325
9.7 I/O queues	268	K SuperBasic token types	328
9.8 Simple serial I/O	268	L Arithmetic package op-codes	329
9.9 Directory device drivers	269	M Operating System variables summary	330
9.9.1 Definition blocks	269	N Channel definition block structure	333
9.9.2 Access layer	270	P File system channel definition block	334
9.10 Slave blocks	272	Q Job control block	335
9.11 Parallel printer driver example	273	R Common heap header	336
9.11.1 Introduction	273	S Window block definition	337
9.11.2 Device driver program	274	T Microdrive backup utility program	338
9.11.3 Program operation	276	U Parallel printer interface circuit	339
10 SuperBASIC	278	Bibliography	341
10.1 Introduction	278	Glossary	342
10.2 The name table	278	Index	347
10.3 The name list	281		
10.4 The variable value area	281		
10.5 Examples of variable storage	282		
10.6 Passing parameters to procedures/functions	283		
10.7 Writing machine code procedures	285		
10.7.1 Introduction	285		
10.7.2 Creating name table entries	285		
10.7.3 The arithmetic stack	287		
10.7.4 Getting procedure arguments	287		
10.7.5 Returning function values	288		
10.7.6 Returning parameter values	288		
10.8 Resident procedure to toggle screens	289		
10.8.1 Two screen support program	289		
10.8.2 How the program works	292		
10.9 Implementing BPUT# as a procedure	293		
10.9.1 How the program works	295		